

Thee Metre Levelawn

Basic Assembly Instructions

British Manufacturing Solutions
Manufacturers of Turf Care Tools & Sports Accessories
Barton Hill Way , Torquay . TQ2 8JG UK
Tel: 01582 758444 Email: Info@bmsproducts.co.uk

Required Tools

- Spanner set
- Flat surface for assembly
- Small objects for use as packers (coins work well)



Assembly Steps

1. **Prepare the work area**
 - Find a large, flat surface for assembly.
2. **Position the main channels**
 - Stand the two main 'C' channels upright, both facing the same direction.
3. **Place the inner bars**
 - Position the two inner flat bars between the outer 'C' channels.
4. **Arrange the crossbars**
 - Place the 5 mounting cross bars across the main channels as shown in the diagram.
 - Note: All crossbars should face the same direction.
5. **Attach crossbars**
 - Bolt the 5 crossbars onto the inner bars.
 - Do not fully tighten the bolts yet.
6. **Square the frame**
 - Place packers (coins work well) under the ends of the inner flat bars.
 - Tighten the end bolts.
 - Check the weight distribution: a. Feel the weight on each corner of the frame. b. If you detect any difference, gently twist the frame until each corner feels to have the same weight.
 - Alternatively, use suitable tools to ensure accurate squareness during assembly.
7. **Finalise assembly**
 - Insert packers under the edge of the flat bars.
 - Tighten all bolts, ensuring a small gap between the outer 'C' channels and the inner flat bars. This gap allows material to pass under the middle of the Levelawn.

Using Your Levelawn

- **For spreading dressing:**
 - Pull the Levelawn with the flanges of the 'C' channel leading.
 - Attach pull chains to the centre or rear holes of the crossbars.
- **For rubbing in and finishing:**
 - Pull the Levelawn with the flat side of the 'C' channels leading.
 - Attach pull chains to the middle or front holes of the crossbars.